




Corrosion: Meeting Tomorrows Performance Needs with Graphene Nano-Platelets

Western Coatings Show


Andy Gent, Lynn Chikosha, Matthew Sharp, William Weaver, John Willhite



Introduction




www.appliedgraphenematerials.com



Introduction


- There are mixed literature reports of the use of Graphene within anticorrosive coatings
 - Corrosion performance enhancement or performance reduction?
- A variety of mechanisms have been proposed in the literature by which
 Graphene delivers anticorrosion performance
 - Physiochemical process (restricting uptake of water, oxygen and salts)
 - Electrochemical activity.






Introduction


- Plate-like materials such as glass flake and micas have been used as barrier pigments to provide a tortuous path in anticorrosion primers.
- Graphene offers a step change two-dimensional structure delivering:
 - High aspect ratio
 - High surface area
 - Low volume density
- Electrochemical activity due to Graphene's conductivity is dependent on:
 - Graphene type
 - Loading level
- This work provides preliminary corrosion performance results relating to commercially available Graphene nanoplatelet (GNP) products.





AGM Graphene Nano-Platelets






Graphene Nano-Platelets – AGNP-35

- AGM GNPs are manufactured using proprietary and patented bottom up synthesis process
- Graphene, composed of very thin, crumpled sheets, typically 5-7 atomic layers with approximately 5% oxygen
- Very low density and high surface area, enabling enhanced corrosion resistance at very low loadings.
- Recommended active Graphene addition between 0.025% to 0.1% weight of total paint formulation






Delaying Time to Corrosion Onset

Impact of Corrosion...

- In the US alone, it's estimated to cost over \$450bil/yr, or nearly 3% of GDP
- Estimates suggest that the total cost of corrosion globally to \$2.5trillion/yr

	Agriculture	Industry	Services	Total	Total	
Economic	CoC	CoC	CoC	CoC	GDP	CoC
Regions	US\$ billion	% GDP				
United States	2.0	303.2	146.0	451.3	16,720	2.7%
India	17.7	20.3	32.3	70.3	1,670	4.2%
European Region	3.5	401	297	701.5	18,331	3.8%
Arab World	13.3	34.2	92.6	140.1	2,789	5.0%
China	56.2	192.5	146.2	394.9	9,330	4.2%
Russia	5.4	37.2	41.9	84.5	2,113	4.0%
Japan	0.6	45.9	5.1	51.6	5,002	1.0%
Four Asian Tigers + Macau	1.5	29.9	27.3	58.6	2,302	2.5%
Rest of the World	52.4	382.5	117.6	552.5	16,057	3.4%
Global	152.7	1446.7	906.0	2505.4	74,314	3.4%






Delaying Time to Corrosion Onset

Target Benefits...

- Improved coating durability and time to corrosion onset.
- Extension of coating life allowing increased time between maintenance intervals.
- Significant reduction in repair and re-paint costs over the lifetime of the coating
- Potential to reduce coating complexity as well as number of layers in a system







Previous Investigation in Anti-Corrosion

Previously, AGM has developed and reported meaningful anticorrosive performance gains in solvent based systems.


• For example, performance of a standard industrial primer was extended from less than 1000 hours to over 5000 hours (Prohesion Testing) with the addition of Genable® 3000, a graphene based metal free active anti-corrosion additive.






Project Objectives


- To demonstrate compatibility of the graphene dispersion with standard industrial water based coating formulations
- Develop further understanding of the mechanisms of protection
- Identify a significant uplift in anti-corrosion performance through the incorporation of a graphene nanoplatelet dispersion in to water based industrial coatings






Genable® 1250 – Water Based Graphene Dispersion

- Development of water based coatings remains a focus for industry formulators.
- Driven by the continuing tightening of regulations brought in to reduce the impact that solvent-based coatings have on both worker health and the environment.
- One of the key challenges for water-based coatings is to significantly improve their anti-corrosion performance in line with solvent based systems. In doing so, this will fully extend the use of water-based systems to broader industrial protective coatings.





Genable® 1250 – Water Based Graphene Dispersion


AGM supplies its Graphene nanoplatelets in stable dispersions that are:

- Ready to use and easy to incorporate in existing industrial systems
- Available in a number of safe to handle formats
- Optimized to impart specific performance enhancements


Genable® 1250 – AGM's Water-based Graphene Dispersion:

- Milled to a controlled and optimised particle size to optimise barrier properties
- 6 months shelf life
- 0.5% Graphene loading by weight but has a Graphene volume solids of 51%






Experimental




www.appliedgraphenematerials.com



Prototype Paint Formulation

Material	Control	Graphene DTM	Graphene Primer	
Deionised Water	6.1%	6.6%	5.5%	
Dispersant	1.8%	2.0%	1.6%	
Defoamer	0.4%	0.5%	0.4%	
Titanium Dioxide	26.0%	10.1%	23.4%	
Rheology Modifier	1.7%	1.8%	1.5%	
Alkyd Acrylic Resin	60.3%	65.1%	54.2%	
Ammonia (29%)	0.4%	0.5%	0.4%	
Combination Dryer	0.7%	0.7%	0.6%	
Wetting Agent	0.3%	0.3%	0.3%	
Flow Additive	0.5%	0.5%	0.5%	
Anti-Skinning Additive	0.8%	0.9%	0.8%	
Flash Rust Inhibitor	1.0%	1.0%	1.0%	
G enable® 1250	-	10.0%	10.0%	
Total	100%	100%	100%	
Graphene Loading	None	0.05%	0.05%	






Work Programme – Part 1

Test Program I: Initial Scoping

- Prototype primer formulations were developed based on an alkyd acrylic resin.
- Graphene nanoplatelets introduced with the addition AGM industry leading stabilised water-based GNP dispersion, Genable® 1250
- Coatings applied to abraded steel, blasted steel and iron phosphated steel
- Films were applied using drawdown bar at a wet film thickness of 150 microns
- Dry film thickness achieved for all systems was ~50 microns
- Dried under ambient lab conditions for 7 days
- Tested up to 1000 hours on Neutral Salt Spray






Neutral Salt Spray after 1000 hours – Creep Assessments

Neutral Salt Spray Testing using ISO 9227:


- A ladder study of increasing Genable® 1250 loadings in a standard alkyd-acrylic primer system was tested against a blank control primer
- Formulations tested on three substrates blasted steel, abraded steel and iron phosphated (Bonderite) steel
- Panels were visually assessed for creep, blistering and break-through corrosion after 1000 hours





Neutral Salt Spray after 1000 hours

Average Creep (mm) across the Scribe of GNP Primer Ladder Study



• With each loading of graphene, a significant reduction in the levels of creep was recorded compared to the control



Neutral Salt Spray – Visual Assessment

Abraded Steel




Control (No GNP)


PVC: 20



10% Genable ® **1250**

PVC: 30





Test Programme – Part 2

Further development of graphene enhanced Direct-To-Metal and Primer formulations

- Viscosity
- Colour
- Gloss


Electrochemical Studies

- Impedance
- Water Uptake

Systems tested:

- Graphene enhanced Direct to Metal formulation
- Graphene enhanced waterbased primer







Effects on Colour and Gloss from GNP


System	PVC	VOC (g/l)	Viscosity (Pa.S)	60° Gloss	L*	a*	b*
Control White Primer	20	10.4	14.6	84.1	96.8	-1.3	4.9
DTM Graphene Paint (grey)	20	11.3	1.8	85.3	68.8	-1.0	-0.8
Graphene Primer (grey)	30	9.4	4.3	80.2	77.1	-1.3	-1.7
Commercial Grey primer	No data	No data	No data	6.4	50.8	-0.8	-1.3

- Graphene addition has minimal impact on the gloss of the paint
- Graphene acts as an excellent black pigment, giving a primer with a light grey hue
- The Graphene paints, in comparison with a commercially available grey primer, were still lighter in shade allowing scope for further colour matching.
- The addition of the high surface area graphene, due to its easy to use dispersed form does not impact on the viscosity of the finished paint





Electrochemical Studies









Electrochemical Impedance Spectroscopy Testing




- Measurements recorded using a Gamry 1000E potentiostat with a Gamry ECM8 multiplexer
- Working electrode test area = 14.6 cm²
- 3.5wt% NaCl electrolyte
- Continuous measurements taken over a 140 hour period.






AC Impedance (EIS) – Zones of Protection

Materials







www.appliedgraphenematerials.com


Confidential Information

Effects on Colour and Gloss from GNP




- The graphene enhanced primer and DTM coatings showed higher impedance values than the graphene-free control.
- Higher level of impedance was achieved with the DTM coating due to PVC.






Water Uptake



- The addition of 10% Genable® 1250 resulted in a significant reduction in water uptake.
- Both systems showed a 35-40% reduction
- The reduction in water uptake suggests the graphene nanoplatelets are improving barrier properties by increasing the tortuous path.






Summary

The test results presented here clearly demonstrated performance gains in waterbased anticorrosive systems:

- Significant reduction in creep
- Reduction in visible corrosion on 3 types of steel tested
- Greater than 35% Reduction in water uptake with the addition of 10% Genable® 1250 in both the DTM and primer formulations.
- Higher impedance values with the graphene coatings compared to the control demonstrating a significant increase in barrier performance







Conclusion

- AGM has developed a range of prototype water-based coatings containing graphene nanoplatelets.
- With minimal impact to coating gloss and a slight drop in L* values, the
 resultant grey coatings were lighter than the commercial grey primer testing
 allowing formulators significant room to colour match.
- With the addition of Graphene nanoplatelets delivers a significant increase in corrosion resistance as well as a reduced creep and water vapour uptake.
- Through adding the high surface area and high aspect ratio graphene nanoplatelets, AGM are able to offer formulators a new toolbox of technology to drive the innovation of water-based anti corrosion coatings.









www.appliedgraphenematerials.com info@appliedgraphenematerials.com

The Innovation Centre,
Wilton Site,
Redcar.
TS10 4RF
United Kingdom



...Graphene in products used by everybody, everyday